



Filter

Canon 52 mm Screw-in Filter Protect	19
Canon 58 mm Screw-in Filter Protect	23
Canon 67 mm Screw-in Filter Protect	48
Canon 72 mm Screw-in Filter Protect	39
Canon 77 mm Screw-in Filter Protect	47
Hoya UV (C) 52 mm	19
Hoya UV (C) 58 mm	19
Hoya UV (C) 62 mm	23
Hoya UV (C) 67 mm	28
Hoya UV (C) 72 mm	28
Hoya UV (C) 77 mm	34
Hoya PRO1 Digital 52 mm	23
Hoya PRO1 Digital 58 mm	26
Hoya PRO1 Digital 62 mm	32
Hoya PRO1 Digital 67 mm	34
Hoya PRO1 Digital 72 mm	36
Hoya PRO1 Digital 77 mm	38

Lens Cap

Lens Cap E-58II	6
Lens Cap E-72II	8
Lens Cap E-77II	7
Lens Cap E-82II	8

Lens Hood

Lens Hood EW-60C	13
------------------	----

Battery

BP-955 4900mAh	188
Battery Pack BP-308	64
Battery Pack NB-4L	42



Power Adapter

Camera Station CS-DC1a	24
Power Adapter CA-930(E)	105
Power Adapter CA-570(E)	48

Accessories

Bluetooth BU-20	56
WiFi WFT-E6 B	544
Battery Grip BG-E6	266
Canon EP-EX15	17
Canon IFC-400 PCU	26

Case-Bag

Soft Leather Case DCC-200	20
Gadget Bag 100EG	49
Gadget Bag 300EG	64
Gadget Bag 10EG	81
Gadget Bag 1EG	97
Carrying Bag SC-2000 SOFT	60
Carrying Bag DCC-CP2	27